



# Grand Aequs and Aequs Bath Fitting Guide

## 1.

Determine where the bath waste is to be positioned. Bring the 40mm waste pipe out of the floor approximately 150mm in front or behind it.

## 2.

Leave tile or floorboards out from under the bath's footprint, to provide a recessed hole approximately 500mm x 400mm x 65mm for the trap and waste outlet to sit in.

## 3.

Fit the trap and flexible waste pipe to the underside of the bath as shown.

## 4.

Attach the flexible hose to the waste pipe outlet.

## 5.

Attach the earth wire to the bonding point provided.

## 6.

Apply a bead of neutral cure sealant around the base of the bath, then bed it into position.

