



# Alvius Bath

## Fitting Guide

**1.**

Determine where the bath waste is to be positioned. Bring the 40mm waste pipe out of the floor 20-30mm within a radius of 750 - 950 mm from it.

**2.**

Leave tiles or floorboards out from under the bath's footprint, to provide a recessed hole approximately 500mm x 400mm x 65mm for the trap and waste outlet to sit in.

**3.**

Fit the trap and flexible waste pipe to the underside of the bath as shown.

**4.**

Attach the flexible hose to the waste pipe outlet.

**5.**

Attach the earth wire to the bonding point provided.

**6.**

Apply a bead of neutral cure sealant around the base of the bath, then bed it into position.

