



# Grande Bateau, Bateau and Petit Bateau Bath

## Fitting Guide

### 1.

Determine where the bath waste is to be positioned. Bring the 40mm waste pipe out of the floor 150 mm in front or behind it.

### 2.

Leave tiles or floorboards out from under the bath's footprint, to provide a recessed hole approximately 500mm x 400mm x 65mm for the trap and waste outlet to sit in.

### 3.

Fit the trap and flexible waste pipe to the underside of the bath as shown.

### 4.

Attach the flexible hose to the waste pipe outlet.

### 5.

Apply a bead of neutral cure sealant around the base of the bath, then bed it into position.

