

# Important Please Read Before Installation

## Flux can damage the bath/basin finish

If the water system has been fitted using soldered joints you must flush the system into a bucket before filling the bath/basin to remove any flux residue from the pipes

## Seals Must Be Tested Prior To Installation

If your bath has been supplied fitted with an overflow kit please ensure that all rubber seals are tested prior to final installation as the seals can move in transit and are therefore not guaranteed.