



Rotundus Bath

Fitting Guide

1.

Determine where the bath waste is to be positioned. Bring the 40mm waste pipe out of the floor 20-30mm within a radius of 750 - 950 mm from it.

2.

Leave tiles or floorboards out from under the bath's footprint, to provide a recessed hole approximately 500mm x 400mm x 65mm for the trap and waste outlet to sit in.

3.

Fit the trap and flexible waste pipe to the underside of the bath as shown.

4.

Attach the flexible hose to the waste pipe outlet.

5.

Apply a bead of neutral cure sealant around the base of the bath, then bed it into position.

